



CONCRETE MUST FULLY SUPPORT THE FRAME ALL THE WAY TO THE INSIDE EDGE OF THE FRAME
 CONCRETE STRENGTH MUST BE A MINIMUM STRENGTH OF 32 MPA
 ENSURE CONCRETE IS FREE OF VOIDS
 SCREED OFF CONCRETE TO A NEAT FINISH
 (COVER RIBS AND EDGES SHOULD BE VISIBLE)
 ALLOW 24 HOURS TO CURE BEFORE ATTEMPTING TO REMOVE ANY COVERS

3		
REV:	DATE:	REVISION DETAILS:

HaveStock
 Access Covers & Grates
 452 NEWMAN ROAD GEEBUNG (07) 32165000

CLASS D 2 PART COVERS
 ACCESS COVER AND FRAME

HAV- 1270.1200