

Humes Fibre Loop Bracket Installation

Installation Guidelines

Installing into a plastic chamber:

- 1) Using the three self tapping screws provided, locate bracket onto chamber wall and drive the three screws into wall
- 2) Ensure bracket is attached securely

Installing into a concrete chamber:

- 1) Locate bracket onto chamber wall and mark the three hole positions on the chamber wall
- 2) Drill holes and insert the three drop-in anchors
- 3) Position bracket and knock the three bolts supplied through into anchors
- 4) Tighten bolts to ensure the bracket is securely held on the chamber wall

Installing fibre:

- 1) Unhook the rubber band
- 2) Insert loop into bracket
- 3) Replace rubber band

Fibre Loop Bracket Kit Contains:

- 1 x pre-assembled bracket
- 1 x rubber band
- 3 x 65mm x 12 gauge hex drive self tapping screws
- 3 x 6mm drop-in anchors and M6 x 30 304 S/S bolts and washers



Disclaimer: Buyers and users must make their own assessment of our products under their own conditions for their own use. All queries regarding product suitability or purpose or installation should be directed to the nearest Humes office for advice and assistance. Availability of product may differ slightly from that available in your area. © Copyright Humes Pipeline Systems 2008.