

Christchurch Head Office PO Box 16276, Hornby, Christchurch 8441 Phone 03 344 0262 Fax 03 344 0267 Email office@oasisclearwater.co.nz www.oasisclearwater.co.nz

Oasis Clearwater Head Office Phone 0800 62 74 72 Distributors Nationwide Phone 0800 48 48 49

Essential Guidelines For The Care Of Your Wastewater System

- Do not pour greases, fats and oil down any drain
- Do not attach a waste disposal unity to your sink for disposal of foods that are difficult to biodegrade
- Do not dispose of paints or any household chemicals in the drain. Use liquid cleaners/washing powders and biodegradable products where possible
- Do not dispose of automotive fluids down any drain including petrol, oil, transmission or brake fluid, grease or antifreeze
- Do not rinse pesticides, herbicides or any other toxins down the drain
- Do not dispose of any non-biological item in your toilet or drains e.g. cigarette butts, disposal nappies or feminine hygiene products
- Do not waste unnecessary amounts of water while washing dishes or thawing foods. Utilise water saving devices where possible
- Do not run half loads in the dishwater or washing machine. Where possible stagger laundry wash loads throughout the week
- Do not use chemicals to "clean out" your system
- Do not attach "clean water" sources such as sump pumps or storm water to your wastewater system

Remember your wastewater system is a living system that requires ongoing servicing and maintenance. Please ensure it is serviced every six months. If your system is alarming it is important you contact your Installer or Service Agent immediately.